

HOW DO I START MY SHIFT?



A: Turn on G7 Bridge first

Press and hold the power button on G7 Bridge. When the SureSafe™ light is solid green, you can proceed.

Turn on G7x after G7 Bridge is connected

Press once firmly on the power button on G7. When the SureSafe™ light is solid green, it is safe to work.

NOTE: Always turn on G7 Bridge before G7.

WHY IS G7 FLASHING GREEN?



A: You have lost connection to G7 Bridge

Your safety is not being monitored, try moving closer to bridge and ensuring bridge has a clear view of the sky.

HOW DO I CALL FOR HELP?



A: Pull the red latch if you require assistance

Your device will alert monitoring personnel.

HOW DO I BUMP OR CALIBRATE?



A: Use the up and down arrows to navigate to bump test or calibrate from the main menu

From there, follow the instructions on G7 screen.

WHY IS G7 BLINKING YELLOW?



A: Your device is asking you to confirm that you are OK

Press the latch once to check-in and silence the beeping. If you are unsure why G7 is in yellow pending alarm, you can read the screen for clarification.

WHY IS G7 FLASHING BLUE?



A: Monitoring personnel have received your remote alert, and are responding by following your emergency protocol

No action is required from you. Monitoring personnel will be contacting you via text message to ensure you are OK. Once monitoring personnel have resolved your alert, the LiveResponse blue light will shut off.

WHY IS G7 RAPIDLY BLINKING YELLOW?



A: G7 Has a message for you.

Read your G7 Screen, it has a message that could be an incoming text message, network connection interruption, low battery, or a warning alarm regarding gases or sensors.

To silence this alarm, press and hold the up and down arrows for three beep cycles.

HOW DO I END MY SHIFT?



A: Turn off G7 first

Press once firmly on the power button on G7. When the SureSafe™ light is off, you can proceed.

Turn off G7 Bridge after all connected G7x have been turned off

Press and hold the power button on G7 Bridge. When the SureSafe™ light is off, your system is logged off and your safety is no longer being monitored.

Charge after every shift

Always charge G7 after every shift, and leave charging when not in use.

NOTE: Always turn off G7 before G7 Bridge

WHY IS G7 RAPIDLY BLINKING RED?



A: G7 has communicated to monitoring personnel

G7 has immediately communicated a red alert to monitoring personnel. If you are unsure why G7 is in red alert, you can read the screen for clarification.

To silence this alarm, press and hold the up and down arrows for three beep cycles. This will not cancel the alert communicated to monitoring personnel.